

OF COPIES RECEIVED		
DISTRIBUTION		
T A F E		
E		
S.G.S.		
AND OFFICE		
OPERATOR		

**HUECO OFFICE O. C. C.
NEW MEXICO OIL CONSERVATION COMMISSION**

MAY 11 3 01 PM '66

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-8876
7. Unit Agreement Name -
8. Farm or Lease Name New Mexico State "AA"
9. Well No. 1
10. Field and Pool, or Wildcat Allison Penn
12. County Roosevelt

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator Sunray DX Oil Company
3. Address of Operator P. O. Box 1416, Roswell, New Mexico
4. Location of Well UNIT LETTER H , 1980 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 36 TOWNSHIP 8S RANGE 36E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4066 (D.F.)

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Place 25 sx cnt plug over present perfs (9652-9668) from PBTD 9703 to a-prox 9400'.
- Cut off 4 1/2" csg at approx 9100' (TOC 9130'). Pull csg, fill hole w/mud.
- Place 50 sx cnt plug in and out of 4 1/2" stub. Approx 9175-8950'. (To cover top of Hueco @ 9002'.)
- Place 25 sx cnt plug over Abo from approx 7760-7695'.
- Place 25 sx cnt plug over Tubb from approx 6950-6875'.
- Place 25 sx cnt plug over Clearfork from approx 6220-6145'.
- Place 25 sx cnt plug over Gloriotta from approx 5560-5485'.
- Place 25 sx cnt plug in and out of base of 8 5/8" csg. (Set at 4169', cnt'd to surface) approx 4200'-4100'.
- Mud to be left in hole between all plugs.
- Place 10 sx cnt plug @ surface, install dry hole marker and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED B. F. Brawley TITLE District Engineer DATE May 10, 1966

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: