

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

MAY 11 3 01 PM '66

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		<p>4. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/></p>
<p>1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- TA Oil Well</p>		<p>5. State Oil & Gas Lease No. E-8876</p>
<p>2. Name of Operator Sunray DX Oil Company</p>		<p>7. Unit Agreement Name -</p>
<p>3. Address of Operator P. O. Box 1416, Roswell, New Mexico</p>		<p>8. Farm or Lease Name New Mexico State "AA"</p>
<p>4. Location of Well UNIT LETTER B, 660 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 36 TOWNSHIP 8S RANGE 36E NMPM.</p>		<p>9. Well No. 2</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 4074 (D.F.)</p>		<p>10. Field and Pool, or Wildcat Allison Penn</p>
<p>12. County Roosevelt</p>		

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ PULL OR ALTER CASING ☐ OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐ COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐ CASING TEST AND CEMENT JOB ☐ OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Place 25 sx cmt plug over present perms (9651-9673') from PBTD 9703' to approx 9403'.
- Cut off 4 1/2" csg at approx 8700' (TOC 8730'). Pull csg, fill hole w/mud.
- Place 25 sx cmt plug in and out of 4 1/2" csg stub. Approx 8750-8575'. (Hueco covered by pipe)
- Place 25 sx cmt plug over Abo approx 7760'-7685'.
- Place 25 sx cmt plug over Tubb approx 6950-6875'.
- Place 25 sx cmt plug over Clearfork, approx 6220-6145'.
- Place 25 sx cmt plug over Glorieta, approx 5560-5485'.
- Place 25 sx cmt plug in and out of base of 8 5/8" csg. (set at 4159', cmt'd to surface). approx 4200-4100'.
- Mud to be left in hole between all plugs.
- Place 10 sx cmt plug @ surface, install dryhole marker and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED B.F. Brawley TITLE District Engineer DATE May 10, 1966

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: