Form Approved. rm Approved. dget Bureau No. 42-R1424

UNITED

O STATES PARES NEW MEXICO 8324

000.40	proget	Dureau	140.	42-	•
83240 5. LEASE		/	12,	;: _{>}	

9.,,,,			. •
DEPARTMENT	OF	THE	INTERIOR
GEOLOG	CAL	SUR	VFY

eа	<u>eral</u>	<u> </u>	055	4773	Հ	
6.	IF INC	IAN .	AL LO	TTEE	ΩR	TDII

GEOLOGICAL SURVEY	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir, Use Form 9–331–C for such proposals.)	7. UNIT AGREEMENT NAME 8. FARM OR LEASE NAME
1 61	· 1
1. oil gas other Injection	Lauck-Federal
Injection	9. WELL NO.
2. NAME OF OPERATOR	10
Champlin Petroleum Company	10. FIELD OR WILDCAT NAME
3. ADDRESS OF OPERATOR	Chaveroo-San Andres
P. O. Box 7946, Midland, TX 79708	11. SEC., T., R., M., OR BLK. AND SURVEY OR
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	AREA
below.)	Sec 29, T7S, R33E
AT SURFACE: 1980' FSL & 660' FWL	
AT TOP PROD. INTERVAL: Same	12. COUNTY OR PARISH 13. STATE
AT TOTAL DEPTH	Roosevelt NM
Salle	14. API NO.
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE,	
REPORT, OR OTHER DATA	15 FLEVATIONS (CHOW DE KOR AND HID)
	15. ELEVATIONS (SHOW DF, KDB, AND WD) 4403 WD
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:	T703 WJ
TEST WATER SHUT-OFF \(\square\)	Taking Commence
FRACTURE TREAT	and the second s
SHOOT OR ACIDIZE	
	(NOTE: Report results of multiple completion or zone
MULTIPLE COMPLETE	5.12.180 OIL 1 OITH 3-330.)
CHANGE ZONES	12
ABANDON*	-
(other)	-
(differ)	• · ·
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly, state including estimated date of starting any proposed work. If well is di measured and true vertical depths for all markers and zones perfinent. Well has casing leak and is no longer needed for the starting of the starting leak.	rectionally drilled, give subsurface locations and it to this work.)*
Proposed plugging procedure:	
Set CIBP @ 4100 capped w/50 sack cement plug. I point. (Shoule be at approximately 2700'±). I across bottom of salt section (1850' top & 2300 Set 100' cement plug centered at the top of 4-1 cement plug centered at surface casing shoe at of surface pipe with marker installed. Fluid E mud. 24 hour notice prior to setting CIBP.	100' plug across top and 100' D' bottom) if not behind pipe. 1/2" casing stub. Set 100' 370' Set 100'
Subsurface Safety Valve: Manu. and Type	Set @ Ft.

18. I hereby certify that the foregoing is true and correct FITLE Senior Engineer DATE SIGNED W 8/8/84

(Orig. Sgd.) PETER W. CHESTER

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

AUG 15 1984

TITLE

*If 4 1/2" casing free 100' pluse *If 4 1/2" casing free point is above salt section the 100' plugs will be placed inside the 4 1/2" casing. **Tag plug



*See Instructions on Reverse Side

PWC