

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

SUBSEQUENT REPORT OF:

REPAIRING WELL.

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

Will no longer be productive w/ no workover or recompletion possibilities. Propose to P&A as follows:

- 1- Cut & pull 4" casing from free point. (TCMT- 2742')
 - 2- Re-place hole w/ mud.
 - 3- Set 35' 5x cement plug from PBD-3875' to cover pipe: 4041-4276'
 - 4- " 35 " " " On + out of casing still.
 - 5- " 35 " " " Across B Salt @ 2970.
- { Depending where casing is cut, Steps 4+5 may be
 { combined to form one plug of a 66' minimum if
 { top of casing and bottom of salt are within
 { 300' of each other. If necessary increase cement
 { volume to insure 100' plug. }
- 6- Set 35' 5x across T Salt @ 1845 (1915-1775')
 - 7- Set 35' 5x in + out of 8 7/8" CSA 368.
 - 8- " 10 " @ surface & erect P & A marker.
 - 9- Make final cleanup and restore ground to contour & level location.

848 CS4 3680 (circ)

18. I hereby certify that the foregoing is true and correct.

TITLE ADMINISTRATIVE ASSISTANT

(This space for Federal or State office use)

TITLE

~~CONDITIONS OF APPROVAL, IF ANY:~~

18GS-H

1-DIR

1 - SUS P

1-REV

11/10/09

***See Instructions on Reverse Side**

APPROVED
AS AMENDED
NOV 6 1975
Side ARTHUR R. BROWN
DISTRICT ENGINEER