

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY
Artesia, NM 88210

NM OIL SUBMIT IN TRIPLICATE*

(Other Instructions
on reverse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.Federal N.M. 0108997
6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Champlin Petroleum Company	8. FARM OR LEASE NAME Farrell-Federal
3. ADDRESS OF OPERATOR 300 Wilco Building Midland, TX 79701	9. WELL NO. 7
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FS&EL Sec. 30, T-7-S, R-33-E	10. FIELD AND POOL, OR WILDCAT Chaveroo (San Andres)
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 30, T-7-S, R-33-E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4445 DF	12. COUNTY OR PARISH Roosevelt
	13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)



17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well uneconomical to produce.

Proposed plugging procedure.

Set CIBP @ 4100' and cap w/50' cement. Locate 4-1/2" casing free point. (Should be at approximately 1400' +). Cut off 4-1/2" OD casing at free point. Set 100' cement plug centered at top of 4-1/2" casing stub. Set 100' plug across surface casing shoe @ 375'. Set 10 sx plug in top of surface pipe with marker installed. Fluid between plugs to be 10#/gal mud.

San Andres perfs 4176'-4381'.



18. I hereby certify that the foregoing is true and correct

SIGNED Peter W. Chester

TITLE

District Superintendent
Drilling & Prod. Opr.

DATE

7/12/83

(This space for Federal Approval)

APPROVED BY (Signature) PETER W. CHESTER
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

SEP 13 1983

*See Instructions on Reverse Side