

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other Instructions on
reverse side)Form approved
Bureau of Land Management
No. 42 B1424

NM-0321281

SUNDRY NOTICES AND REPORTS ON WELLS

(Use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use SEPARATE ATTACH FOR PERMIT for such proposals.)1. ☒ CASING WELL ☐ OTHER2. NAME OF OPERATOR
Amoco Production Company3. ADDRESS OF OPERATOR
BOX 68, HOBBS, N. M. 882404. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 1c below.)
At surface

660' FSL x 660' FWL Sec. 29 (UNIT M, SW/4 SW/4)

5. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4142' R. D. B.

7. UNIT AGRICULTURE NAME

8. FARM OR LEASE NAME

PETERSON F1 FED

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT

TODD LOWER SAN AND.

11. SECTION, RANGE, OR BLM. AND
SURVEY OR AREA

29-7-36 NM PM

12. COUNTY OR PARISH

ROOSEVELT

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. LIFETIME PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)

Well ceased production due to casing collapse from
approx 3360' - 3408'. Puller & rods and pump
unable to pull tubing. Cut & pulled tubing from
4244'.

Limited marginal production precludes repair justification.
Propose to P&A as follows:

Spot 25 cu cement plug from 3360 (top of collapse) up.
Spot & pull 4" casing from free point (Est. 2000')
Spot 25 cu plug from 2100' up. (if pulled from below 2100')
and 25 cu in+out of 4" shut b. (if cut above 2100' place
25 cu in+out of 4" shut only)
Spot 25 cu in+out of 8" shoe @ 322'.
Spot 10 cu @ surface and erect P&A marker.

all intervals to be filled w/ mud.

make final cleanup & level location.

17. I hereby certify that the foregoing is true and correct

SIGNED

Roy R. Yeakum

TITLE ADMINISTRATIVE ASSISTANT

DATE OCT 22 1973

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

OCT 29 1973

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

6-4-55-11
1- CIV
1- SUBP
1- R&A