

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator BTA Oil Producers	8. Farm or Lease Name O'Neill 687 Ltd.
3. Address of Operator 104 S. Pecos Midland, Texas 79701	9. Well No. 1-Y
4. Location of Well UNIT LETTER "O" 660 FEET FROM THE South LINE AND 1880 FEET FROM THE East LINE, SECTION 36 TOWNSHIP 8-S RANGE 35-E NMPM.	10. Field and Pool, or Wildcat Vada-Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4131 GL	12. County Roosevelt

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>
PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOBS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>
ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### Proposed Procedure:

Call NMOCC - Hobbs - 505/393/6161 - 24 hrs. advance.  
Hole to be filled w/mud laden fluid.  
Lay down rods & 2-3/8" tbg.  
Set CIBP @ 9750' w/3 sx cmt. on top.  
Cut & pull 5-1/2" csg. T/C @ ± 8100'.  
Set 50 sx cmt @ stub.  
Set 50 sx cmt @ 5477' Glorietta.  
Set 50 sx cmt @ 4070' Base intermediate.  
  
Cut & pull 8-5/8" csg.  
Set 50 sx cmt @ 8-5/8" stub.  
Set 50 sx cmt @ 385' Base surface  
Set 10 sx cmt @ surface.

Install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED James Jones TITLE Production Clerk DATE 9/18/72

APPROVED BY Joe D. Ramey TITLE Orig. Signed by Joe D. Ramey Dist. I, Supv. DATE SEP 21 1972

CONDITIONS OF APPROVAL, IF ANY: