

NM OIL CONS. COMMISSION

Form 9-231
(May 1963)

UNIVERSITY OF NEW MEXICO 88210
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

APPLICANT'S
(Other Instructions on Reverse Side)

Form approved.
Budget Bureau No. 42 R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR Tom Brown, Inc.

3. ADDRESS OF OPERATOR P. O. Box 2608, Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also Space 17 below.)
At surface 660' FNL & 1980' FEL
Unit B

14. PERMIT NO.

15. ELEVATIONS (Show whether FE, BT, GR, etc.)
4016' GR

5. LEASE DESIGNATION AND SERIAL NO.
NM 0234351

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Federal

9. WELL NO.
2

10. FIELD AND POOL, OR WILDCAT
Vada Penn

11. SEC., T., R., M., OR B.L.K. AND SURVEY OR AREA
Sec. 33, T8S, R36E

12. COUNTY OR PARISH
Roosevelt

13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

SOURCE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	☐	WATER SHUT-OFF	☐
FRACTURE TREAT	☐	FRACTURE TREATMENT	☐
SPOOTING OR ACIDIZING	☐	SPOOTING OR ACIDIZING	☐
REPAIR WELL	☐	REPAIRING WELL	☐
OTHER	☐	ALTERING CASING	☐
PULL OR ALTER CASING	☐	ABANDONMENT*	☐
MULTIPLE COMPLETION	☐		
ABANDON*	☒		
CHANGE PLANS	☐		

(Other)

17. IS THE PROPOSED OR COMPLETED OPERATION (Clearly state, in pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give surface location and measured and true vertical depths for all markers and zones pertinent to this work.)

- Set CIBP @ 9700' and spot 25 sxs of cement on top of plug.
- Cut and pull 4 1/2" casing at free point or 8500' whichever is shallower.
- Spot 40 sxs cement plug in 4 1/2" casing stub and tag plug to insure proper placement.
- Spot 100 sxs cement plug at 5500' - 5600'.
- Spot 40 sxs cement plug at 8 5/8" casing shoe and tag plug to insure proper placement.
- Cut and pull 8 5/8" casing at free point.
- Spot 60 sxs plug in 8 5/8" casing stub.
- Spot 60 sxs plug at 12 3/4" casing shoe and tag plug to insure proper placement.
- Spot 25 sxs plug at surface.
- Install P & A marker.

We will notify U.S.G.S. when location is ready for inspection.

* 75' in & out of casing stub.
** 4050 - 3950'
*** 457' - 357'

Collection 9/24/82

RECEIVED
SEP 13 1982

18. I hereby certify that the foregoing is true and correct.

SIGNED James A. Gillham TITLE Southern Division Operation Superintendent DATE 9-2-82

(This space for Federal & State Use Only)

APPROVED BY James A. Gillham DATE SEP 23 1982

CONDITIONS OF APPROVAL, IF ANY:

FOR JAMES A. GILLHAM DISTRICT SUPERVISOR

*See Instructions on Reverse Side