

UNITED STATES SOX 1980
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

ATE
a re

Form approved *com SW-53*
Budget Bureau No. 1004-01-53
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR TOM BROWN, INC.	8. FARM OR LEASE NAME FEDERAL "E"
3. ADDRESS OF OPERATOR P. O. BOX 2608, MIDLAND, TEXAS 79702	9. WELL NO. #1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FSL & 1980' FEL	10. FIELD AND POOL, OR WILDCAT VADA (PENN)
14. PERMIT NO. <i>841</i>	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA SEC. 28, T8S, R36E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4020' GR	12. COUNTY OR PARISH ROOSEVELT
	13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETION ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS. Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.*

1. Reason for P&A - Depleted reserves & uneconomical to produce.
2. Set CIBP @ 9600' w/20'35" cmt on top (perfs 9745-58')
3. Cut & pull 4-1/2" csg @ 7000'. Spot ~~25~~ cmt 50'85" in & out of csg stub. *Tag plug*
4. Cut & pull 2000' of 8-5/8" csg. Spot ~~40~~ cmt 50'60" in & out of csg stub. *Tag plug*
5. Spot 50 sx cmt from 467' to 367' (surface shoe @ 417') *Tag plug*
6. Spot ~~10~~ cmt @ surface, *minimum 50' cmt. plug*
7. Hole will be loaded with mud.

Additional plug: 140' cmt. plug 4670'-3976'. Tag plug

18. I hereby certify that the foregoing is true and correct

SIGNED

Calvin

TITLE

PRODUCTION ENGINEER

DATE

1-20-92

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY: *As modified.*

*See Instructions on Reverse Side

