

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIP
(Other instructions
verse side)

C. C.

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-2958

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Cities Service-Ped.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Undesignated Penn

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 21, T8S, 36E

12. COUNTY OR PARISH 13. STATE

Roosevelt NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

D. B. Baxter & Assoc.

3. ADDRESS OF OPERATOR

P. O. Box 4171 Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface554' FSL 2086' FSL Sec. 21, T8S, 36E
Roosevelt County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4101.4 G

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent
to this work.)*

This well has depleted to a level that we cannot economically continue
to produce it, we therefore propose to plug and abandon the well as
follows:

- 1 - Move in, rig up, pull rods and tubing.
- 2 - Run CIBP on wire line & dump 35' cement above perfs fr 9682-9692'.
- 3 - Load hole w/10% mud laden fluid.
- 4 - Shoot off 5 1/2" csg @ free point est. 6000', pull casing.
- 5 - Run tubing to 5 1/2" casing stub, spot 100' cement plug @ 5 1/2" casing stub.
- 6 - Spot 100' plug @ 5500' (Glorietta) if not behind 5 1/2" casing.
- 7 - Spot 100' plug across 8 5/8" casing shoe fr 4141-4041.
- 8 - Shoot off 8 5/8" casing @ free point est. 1200'.
- 9 - Spot 100' plug @ 8 5/8" casing stub.
- 10 - Spot 100' plug across 12 3/4" casing shoe fr 472-372'.
- 11 - Place 10' cement inside surface.
- 12 - Set permanent dry hole marker.

NOTE: Plugging work will commence 5/25/73

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Agent

DATE

5/23/73

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

MAY 23 1973

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.