

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REOPEN OR PLUG BACK TO A DIFFERENT RESERVOIR, USE APPLICATION FOR PERMIT TO DRILL C-101, FOR S-101 PROPOSALS.)

OIL WELL ☐ GAS WELL ☐ OTHER ☒ - Dry Hole

Name of Operator
Cola Petroleum, Inc.

Address of Operator
Suite 200 - 619 West Texas, Midland, Texas 79701

Location of Well
UNIT LETTER K, 1650 FEET FROM THE South LINE AND 1650 FEET FROM
THE West LINE, SECTION 32 TOWNSHIP 7-S RANGE 37 NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
4072 gr. 4084 KB.

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
K6523

7. Unit Agreement Name

8. Farm or Lease Name
TP - State

9. Well No.
1

10. Field and Pool, or Wildcat
Bluitt-Wolfcamp

12. County
Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK ☐ ALTERING CASING ☐
TEMPORARILY ABANDON ☐ COMMENCE DRILLING OPS. ☐ PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐ CHANGE PLANS ☐ CASING TEST AND CEMENT JOBS ☐
OTHER ☐ OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set cement plug from TD (8287') to 8150' to plug off perf. 8198'-8275'.
- Determine "Free Point" on 4-1/2" csg. at about 7000'. Cut off and pull 4-1/2" csg. Will not cut off below 7100'; Abo 7140'.
- Set 100' cmt. plug 50' in and 50' out of 4-1/2" csg.
- Set 100' cmt. plug from 4960' to 5060' (Glorieta) and 100' plug in and out of base of 8-5/8" csg.
- Run bond log to determine cement top behind 8-5/8" casing. Top of anhydrite at 2012'; will squeeze if required.
- Cut off 8-5/8" csg. above cmt. top. Set 100' plug 50' in and 50' out of the top. A 100' cmt. plug at 2000' may be required.
- Set 10 sxs plug in top of 12-3/4" csg. with proper dry hole marker.

NOTE: All plugs will be set thru tubing.

8. - 100' plug 50/50 shoe 12 3/4" csg.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed Melville B. McMurry TITLE Manager of Engineering DATE 12-11-79
Melville B. McMurry
Orig. Signed By
APPROVED BY Jersey TITLE _____ DATE DEC 13 1979
CONDITIONS OF APPROVAL, IF ANY: