

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Tucker
8. Well No. 1
9. Pool name or Wildcat

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Wallace Oil & Gas, Inc.	
3. Address of Operator 50 Penn Place, Suite 850, Oklahoma City, OK 73118	
4. Well Location Unit Letter <u>K</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>5</u> Township <u>7S</u> Range <u>33E</u> NMPM Roosevelt County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up. Pull tubing. Set 4½" CIBP @ 4100' and cap with 35' of cement.
2. Load hole with mud.
3. Cut and pull 4½" casing @ approximately 3300'.
4. Spot 100' plug @ cut-off stub 50' in 50' out. Tag.
5. Spot 100' plug @ 2462' @ 8 5/8" Shoe 50' in and 50' out. Tag.
6. Spot 100' plug @ 1900'.
7. Spot 100' plug @ 450' - 13 3/8" shoe.
8. Set 10 sk. top hole plug.
9. Install P & A Marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Raymond Maldonado TITLE P & A Supervisor DATE 4-25-89  
505-  
TYPE OR PRINT NAME Raymond Maldonado Cementer, Baber Well Servicing Co. TELEPHONE NO. 393-5516

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

APR 26 1989

Q80 1 2 434

RECEIVED  
OFFICE OF THE SECRETARY OF DEFENSE  
WASHINGTON, D.C. 20315  
APR 25 1989  
OCD  
HOBBS OFFICE