

Form 3160-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.

SUBMIT IN TRIPLICATE

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM 54437

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Petroleum Production Management, Inc.

3. Address and Telephone No.

P.O. Box 957 Crossroads, New Mexico 675-2478

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

UL "P" 660' FSL and 660' FEL Sec. 25, T-8-S, R-35-E

8. Well Name and No.

Conquest Federal

9. API Well No.

30-041-20779

10. Field and Pool, or Exploratory Area

Vada Penn 62456

11. County or Parish, State

Roosevelt. N.M.

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Tubing parted coming out of hole on 12-2-93, casing parted and could not get below 3900'. Worked 14 days with no success.

1. Move in and rig up plugging unit.
- * 2. Set CIBP at 3900'. Spot 50' of cement on top of plug. Cement retainer.
3. Load hole with salt gel mud.
4. Cut and pull 5 1/2" casing (approximately 3850'). Spot 100' cement plug 50' inside and 50' outside of 5 1/2" casing stub. Tag plug.
5. Spot 130' cement plug at base of 8 5/8" casing at 3200'.
6. Cut and pull 8 5/8" casing from 470'. Spot 150' cement plug 50' inside and 100' outside to cover the bottom of the 13 3/8" at 426' with 50'. Tag plug.
7. Spot 50' cement plug at surface. Install dry hole marker. Clean location.

* attempt to pump cement into & below parted area of 5 1/2" casing by setting a cement retainer in 5 1/2" casing just above the part & squeezing with 200 to 300 sacks of cement.

14. I hereby certify that the foregoing is true and correct

Signed

Title District Superintendent

Date 9-20-94

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side