

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

LEWIS B. BURLESON

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-7662	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Injection		7. Unit Agreement Name Caprock Queen	
2. Name of Operator Lewis B. Burleson, Inc.		8. Farm or Lease Name State A	
3. Address of Operator Box 2479, Midland, Texas 79702		9. Well No. 3	
4. Location of Well UNIT LETTER <u>K</u> , <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>34</u> TOWNSHIP <u>14 South</u> RANGE <u>31 East</u> NMPM.		10. Field and Pool, or Wildcat Caprock Queen	
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Chaves	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This is a shut-in well. Total Depth: 3101'
 Surface Casing: 8 5/8" at 257' w/150 sx
 Prod. Casing: 4 1/2" at 3075' w/75 sx
 Open hole at 3075' to 3101'
 Top of Salt: 1250'

1. Pump 100 foot plug above perfs in casing being approximately 25 sx. Then tag plug.
2. Set CIBP @ 268'. Perforate squeeze holes @ 260' to spot 45 sack plug in 4 1/2" and between 4-1/2' and 8 5/8" surface casing.
3. Cap with 10 sacks cement at surface
4. Install marker

THE OPERATOR MUST BE NOTIFIED 24
 HOURS PRIOR TO THE BEGINNING OF
 PLUGGING OPERATIONS FOR THE C-103
 TO BE APPROVED.

Revised

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Steve Burleson TITLE Vice President DATE 6-25-87

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT 1 SUPERVISOR

TITLE _____

DATE JUL 9 1987

CONDITIONS OF APPROVAL, IF ANY: