

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIP DATE*
(Other instruction re-
verse side)Form approved.
Budget Bureau No. 42-R1424.5. LEASE DESIGNATION AND SERIAL NO.
NM-0174830-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Mona Federal9. WELL NO.
110. FIELD AND POOL, OR WILDCAT
Tobac-Penn.11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
Sec. 17, T-8S, R-33E12. COUNTY OR PARISH
Chaves13. STATE
N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐2. NAME OF OPERATOR
Atlantic Richfield Company3. ADDRESS OF OPERATOR
P. O. Box 1978, Roswell, New Mexico 882014. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface**1980' FEL, 660' FSL (Unit Letter O)**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4403' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETION ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Production from this well has declined to 2 or 3 BOPD, no water.
A 500 gallon acid job in March, 1969 failed to stimulate production.
No other zones of interest are present in this well. We propose to
P & A in the following manner:

1. Set CIBP at approx. 8890' and cap w/30' of cement.
2. Shoot off and recover 4-1/2" casing as deep as possible.
(Top of cement at 7700'.)
3. Set cement plugs as follows:
 - a. 30 sx in and out of 4-1/2" stub.
 - b. 30 sx across top of Glorieta, from 4880-4980'.
 - c. 30 sx in and out of 8-5/8" casing shoe at 3594'.
 - d. 10 sx in top of well.
4. 13-3/8" & 8-5/8" casing strings will remain intact. 10#/gal salt gel mud will be left between all plugs.
5. Location will be cleared and levelled and dry hole marker erected in accordance with existing regulations.

18. I hereby certify that the foregoing is true and correct

SIGNED **O. D. Bretches**TITLE **Dist. Drlg. Supervisor**DATE **4-29-69**

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

*See Instructions on Reverse Side

APPROVED
APR 30 1969
ARTHUR R. BROWN
DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.