

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-9089

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Drilling Well</b>	7. Unit Agreement Name
2. Name of Operator <b>HUMBLE OIL &amp; REFINING COMPANY</b>	8. Farm or Lease Name <b>New Mexico State "BW"</b>
3. Address of Operator <b>Box 2100, Hobbs, New Mexico 88240</b>	9. Well No. <b>4</b>
4. Location of Well UNIT LETTER <b>"J"</b> 1988 South 1997 FEET FROM THE LINE AND FEET FROM East 16 8-S 33-E THE LINE, SECTION TOWNSHIP RANGE NMPM.	10. Field and Pool, or Wildcat <b>Tobac</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4398 DF</b>	12. County <b>Chaves</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Tops: Rustler 1848	Glorieta 4946	Bough "C" 8971
Yates 2364	Tubb 6419	
Queen 3041	Abo 7310	
San Andres 3549	Wolfcamp 8123	

- Spot 20 SK plug from 9100-8900 feet.
- Cut off & recover approximately 6400 feet 4½" casing (Cmt. Top 6500').
- Spot 20 SK plug from 6450-6350 feet.
- Spot 25 SK plug from 4946-4846 feet.
- Spot 25 SK plug from 3660-3560 feet (Tie in Open Hole to 7-5/8" Intermediate Casing.
- Spot 10 SK plug from 40' to surface.
- Install dry hole marker.
- Clean and level location.
- Mud laden fluid between plugs.
- No. 7-5/8" casing to be pulled.

Verbal approval obtained from Eric Engbrecht 11:13 A.M. 5-20-65  
No Offset Operators.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. J. Davis TITLE District Adm. Supvr. DATE 5-21-65

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: