

OF COPIES RECEIVED	
DISTRIBUTION	
ANTA FE	
ILC	
J.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO RE-ENTER OR RE-LEASE TO A DIFFERENT RESERVOIR. USE APPLICATION FOR REPORT ON PRODUCE CHECK FOR SUCH PROPOSALS.)		5a. Indicate Type of Lease State ☐ Fee ☒
6. Name of Operator UNION TEXAS PETROLEUM CORPORATION		7. Unit Agreement Name
8. Address of Operator 1300 Wilco Building, Midland, Texas 79701		8. Name of Lease Name Crosby "17"
9. Location of Well UNIT LETTER A 660 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 17 TOWNSHIP 8-S RANGE 30-E NMPM.		9. Well No. 3
10. Elevation (Show whether DF, KT, GR, etc.) 4129' GI		10. Field and Pool, or Wildcat Cato (San Andres)
11. County Chaves		

6. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☒	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOBS ☐	OTHER ☐

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU - Install BOP - Pull rods & tubing.
2. Test csg. to locate leak. Upon locating, set BP 150' below leak and top w/50' of sand. Establish circ. thru leak.
3. Squeeze w/200 sx. Class "C". Drill out cement to top of sand above BP.
4. Pressure test to 500#. Repeat squeeze if necessary. Pull BP out of hole.
5. Perforate 3428-3438' & 3282-3298; w/1 JSPF. Total of 28 holes.
6. Set BP at 3500'+ & pkr. @ 3400'+. Acidize w/1500 gal. 15% Ne HCL.
7. Flow well down, release pkr., retrieve BP, pull up to 3350. Set BP @ 3350'+.
8. Move pkr. & set @ 3270'+. Acidize w/4000 gal. 15% Ne HCL & 630# 50/50 Benzoic acid flakes & rock salt.
9. Flow well down. Pull BP & pkr. out of hole.
10. RD BOP, install wellhead, run tbg., rods & pump.
11. Return well to production.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Floyd S. Handysell</u>	TITLE <u>Production Analyst</u>	DATE <u>12/21/79</u>
APPROVED BY <u>Jerry Sexton</u>	TITLE <u>Dist 1, Supv.</u>	DATE <u>DEC 27 1979</u>
CONDITIONS OF APPROVAL, IF ANY		