

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION - C. C.

JUL 29 10 01 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☐ GAS WELL ☐ OTHER- <u>DRY HOLE</u>	7. Unit Agreement Name <u>C</u>
2. Name of Operator <u>PAN AMERICAN PETROLEUM CORPORATION</u>	8. Farm or Lease Name <u>CROSBY "J"</u>
3. Address of Operator <u>BOX 68, HOBBS, N. M. 88240</u>	9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>D</u> <u>990</u> FEET FROM THE <u>NORTH</u> LINE AND <u>660</u> FEET FROM THE <u>WEST</u> LINE, SECTION <u>34</u> TOWNSHIP <u>7-S</u> RANGE <u>30-E</u> NMPM.	10. Field and Pool, or Wildcat <u>WILDCAT</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>4100' R D. B.</u>	12. County <u>LEAVES</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Drilled well to a depth of 7800'. Ran logs. No pays below 3526. Plugged back as follows: 255x cement plugs set @ 7800', 6117', 6788' and a CIBP @ 3526' (PBD). Evaluated San Anas: Perforated 3458-68, 94-3511' w/ 2 1/2" SPF. Acidized w/ 1000 gal MCA. No oil or gas. Squeezed w/ 25004 cement. Perforated 3426-34' w/ 2 1/2" SPF. Acidized w/ 1000 gal 15%. No oil or gas. Set CIBP @ 3410' & squeezed w/ 10004 cement. Perforated intervals 3260, 61, 3377, 81, 93, w/ 1 1/2" SPF. Acidized w/ 3000 gal 15%. Dry hole. Propose to P: A as follows: Spot 35 set cement plug across perfs. Shoot & pull 8 5/8" from approx 1500'. 255x plug in & out of Stubs 25 set @ 1050 (T 3000), in & out of 1878" Cog shoe @ 283'; 105x @ surface w/ P: A marker. Make final cleanup and restore ground to contour.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John W. Remyan AREA SUPERINTENDENT
TITLE Geologist DATE JUL 25 1969
APPROVED BY 1-NSW DATE JUL 29 1969
CONDITION OF APPROVAL, IF ANY: 1-503 P
1-RK4