

## OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER- P&A	7. Unit Agreement Name
1. Name of Operator Yates Petroleum Corporation			8. Farm or Lease Name Lightcap "YR"
2. Address of Operator 207 South 4th St., Artesia, NM 88210			9. Well No. 2
3. Location of Well UNIT LETTER <u>D</u> <u>990</u> FEET FROM THE <u>North</u> LINE AND <u>990</u> FEET FROM THE <u>West</u> LINE, SECTION <u>31</u> TOWNSHIP <u>7S</u> RANGE <u>30E</u> NMPM.			10. Field and Pool, or Wildcat Wildcat SA
15. Elevation (Show whether DF, RT, GR, etc.) 4191' GR			12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
FULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 3475'. POOH with packer and bridge plug. Swabbed well.

Verbal permission obtained from Jerry Sexton, NMOCD, Hobbs, 6-6-84 to plug and abandon well as follows:

- 1) Set CIBP at 3150' w/35' cement.
- 2) Cut 4½" casing at 2450±.
- 3) Spot 25 sx plug 50' in & 50' out of 4½" casing stub at 2450'.
- 4) Spot 35 sx plug at 1000-1100' - across top of salt (1100').
- 5) Spot 35 sx plug at 388-288' across 8-5/8" shoe at 338'.
- 6) Spot 10 sx plug at surface.
- 7) Install dry hole marker and clean location.

Mud will be placed between plugs.

NMOCD, Hobbs, will be notified 24 hours in advance of plugging.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Eddie W. Seay TITLE Production Supervisor DATE 6-7-84

APPROVED BY Eddie W. Seay TITLE Oil & Gas Inspector DATE JUN 11 1984  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JUN 8 1984

OCC  
HOBBS OFFICE