

UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
ALBUQUERQUE, NEW MEXICO 88240

Budget Bureau 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

NM 0347394

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

South Tomahawk Federal

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Tomahawk San Andres

11. SEC., T., R., M., OR BLK. AND
SUBDIVISION OR AREA

Sec. 6, T8S, R32E

12. COUNTY OR PARISH

Chaves

13. STATE

NM

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Fred G. Yates, Inc. Yates Energy Corp

3. ADDRESS OF OPERATOR

Sunwest Centre Suite 1010, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)

At surface

1980' FSL & 660' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4517' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐

PULL OR ALTER CASING

☐

FRACTURE TREAT

☐

MULTIPLE COMPLETION

☐

SHOOT OR ACIDIZE

☐

ABANDON*

☒

REPAIR WELL

☐

CHANGE PLANS

☐

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐

REPAIRING WELL

☐

FRACTURE TREATMENT

☐

ALTERING CASING

☐

SHOOTING OR ACIDIZING

☐

ABANDONMENT*

☐

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)

1. Work to free stuck packer.

a. If we free packer set CIBP @ 4150' with 35' cmt plug on top of it.

b. If unable to free packer cut tbq @ 4150 and set CIBP @ 4148 with 35' cmt
plug on top of it.

2. Work 4 1/2" csg. to find free point. Cut and pull 4 1/2" csg @ free point.

3. Set 100' cmt plug 50' in and 50' out of 4 1/2" csg. Tag this plug.

4. Set 100' Cmt plug @ 1852 50' in and 50' out of 8 5/8" csg. Tag this plug.

5. Set 50' surface plug and install dry hole marker.

6. Clean location.

**Verbal approval as per Peter Chester 3/9/87

18. I hereby certify that the foregoing is true and correct

SIGNED

Shawn Hill

TITLE

Production Clerk

DATE

3/9/87

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED
DATE
PETER W. CHESTER

MAR 16 1987

BUREAU OF LAND MANAGEMENT
RESOURCE AREA

*See Instructions on Reverse Side