

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-10209

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name state 251
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER P, 990 FEET FROM THE South LINE AND 330 FEET FROM THE East LINE, SECTION 28 TOWNSHIP 13-S RANGE 33-E NMPM.	10. Field and Pool, or Wildcat Lazy J-Penn.
15. Elevation (Show whether DF, RT, GR, etc.) 4237' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was shut in on February 10, 1970 following unsuccessful remedial work. A test on 2/6/70 pumped 0 BO & 47 BW in 24 hrs. We now propose to plug & abandon as follows:

Set 5½" CIBP @ approx 9650' and cap w/20 sx cement.
Shoot off and recover 5½" casing from free point.
Set 30 sx cement in and out of 5½" stub.
Set 30 sx cement in and out of 8-5/8" shoe @ 3998'.
Set 20 sx in top of well.

Erect dry hole marker. Clear & level location. 9# salt gel mud will be used to spot plugs. 13-3/8" & 8-5/8" casing will remain intact.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>C.D. Litcher</i>	TITLE Dist. Dirg. Supervisor	DATE 12-11-70
APPROVED BY <i>Joe D. Amey</i>	TITLE SUPERVISOR DISTRICT	DATE DEC 14 1970
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

1-1-1970
OIL CONSERVATION COMM.
WASH. D.C.