

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-01097 ✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-3834
7. Lease Name or Unit Agreement Name Sapphire ALE State
8. Well No. 1
9. Pool name or Wildcat Lazy J Penn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator YATES PETROLEUM CORPORATION	3. Address of Operator 105 South 4th St., Artesia, NM 88210	4. Well Location Unit Letter <u>I</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>660</u> Feet From The <u>East</u> Line Section <u>33</u> Township <u>13S</u> Range <u>33E</u> NMPM Lea County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4248' GR
---	--	--	--	--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows: 5 1/2 at 9739'
TD-10100'

1. Set CIBP at 9400'. Top of 4" liner at 9429'. Cap with 35' of cement.
2. Spot 25 sack cement plug across Abo top at 7665'.
3. Spot 25 sack cement plug from 4200' across 8-5/8" casing shoe at 4085.
4. Spot 35 sack cement plug from 3225' to cover 5-1/2" casing stub at 3176'.
5. Spot 35 sack cement plug from 450' inside 8-5/8" casing to cover 13-3/8" shoe.
6. Spot 15 sack cement plug at surface. Install regulation abandonment marker.

NOTE: All plugs will be spotted thru 2-7/8" tubing. 25#/barrel salt gel plugs will be between all plugs.

NOTIFY NMOCD (393-6161) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE March 24, 1993
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE MAR 29 1993
CONDITIONS OF APPROVAL, IF ANY: