

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER

2. Name of Operator
Charles B. Gillespie, Jr.

3. Address of Operator
P. O. Box 8 Midland, Texas 79702

4. Well Location
Unit Letter 0 : 660 Feet From The South Line and 1980 Feet From The East Line

Section 33 Township 14S Range 33E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

4217 DF

7. Lease Name or Unit Agreement Name

Stevens

8. Well No.

2

9. Pool name or Wildcat

Saunders Permo Upper Penn

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set cast iron bridge plug above perforations at 9800'.
Dump 4 sx cement on top of bridge plug, WOC.
2. Set 25 sx plug at 7700' across top of AB0.
3. Cut off and pull 5 1/2" casing from approximately 6500'.
4. Set 25 sx plug across 5 1/2" casing stub.
5. Set 25 sx plug across 8 5/8" casing shoe at 4170'.
6. Cut off and pull 8 5/8" casing from approximately 1600'.
7. Set 50 sx plug across 8 5/8" casing stub.
8. Set 25 sx plug across 13 3/8" casing shoe at 296'.
9. Set 10 sx plug at top of surface casing.
10. Weld 4" marker to surface pipe, and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE David W. Hastings

TITLE Production Manager

DATE 6/1/89

TYPE OR PRINT NAME

David W. Hastings

TELEPHONE NO. 915-683-1765

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
DRILLING OPERATIONS FOR THE C-103
TO BE APPROVED.

JUN 5 1989

RECEIVED

JUN 5 1989

OCB
HOBBS CENTER