

NUMBER OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
TRANSPORTER	OIL GAS
PRODUCTION OFFICE	
OPERATOR	

(Form C-102)
(Revised 7/1/52)

NEW MEXICO OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

MISCELLANEOUS NOTICES

strict Office, Oil Conservation Commission, before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate Nature of Notice by Checking Below

NOTICE OF INTENTION TO CHANGE PLANS		NOTICE OF INTENTION TO TEMPORARILY ABANDON WELL		NOTICE OF INTENTION TO DRILL DEEPER	X
NOTICE OF INTENTION TO PLUG WELL		NOTICE OF INTENTION TO PLUG BACK		NOTICE OF INTENTION TO SET LINER	
NOTICE OF INTENTION TO SQUEEZE		NOTICE OF INTENTION TO ACIDIZE		NOTICE OF INTENTION TO SHOOT (Nitro)	
NOTICE OF INTENTION TO GUN PERFORATE		NOTICE OF INTENTION (OTHER)		NOTICE OF INTENTION (OTHER)	

OIL CONSERVATION COMMISSION
SANTA FE, NEW MEXICO

Roswell, New Mexico
(Place)

July 23, 1963
(Date)

Gentlemen:

Following is a Notice of Intention to do certain work as described below at the

Shell Oil Company State A Well No. 6 in A
(Company or Operator) Lease (Unit)
NE 1/4 NE 1/4 of Sec. 34, T. 14S, R. 33E, NMPM, Saunders Pool
(40-acre Subdivision)
Lea County.

FULL DETAILS OF PROPOSED PLAN OF WORK

(FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS)

PROPOSED OPERATION: Deepen to test lower Saunders pay zones.

1. Pull rods, pump and tubing.
2. Squeeze cement existing casing perforations gross interval 9789' - 9852' (total 86 holes).
3. Drill out Guiberson packer at 9745' - 50. Clean out hole to PBTD (9859').
4. Deepen hole to approximately 10,000' using tubing, 4 3/4" bit, drill collars and reverse circulating unit. Use oil as drilling fluid.
5. Run GR/N w/CCL and open hole caliper surveys over open hole interval.
6. Run tubing w/Lynes open hole packer. Circulate hole and load w/oil. Set packer immediately below 5 1/2" casing shoe.
7. Swab test open hole.
8. If warranted, open hole will be selectively acidized above and below packer. Volume of acid and packer setting will depend on above swab test and GR/N log analysis.

Approved....., 19.....
Except as follows:

Shell Oil Company
Company or Operator
By..... R. A. Lowery..... Original Signed By
R. A. LOWERY

Position..... District Exploitation Engineer
Send Communications regarding well to:

Approved
OIL CONSERVATION COMMISSION

By.....
Title.....

Name..... Shell Oil Company
Address..... P. O. Box 1858, Roswell, New Mexico 88201