

NO. OF COPIES RECEIVED
DISTRIBUTION
SANTA FE
FILE
ORIGIN
LAND OFFICE
OPERATOR

NEW MEXICO OIL CONSERVATION COMMISSION

Form O-103
Supersedes Old
O-102 and O-103
Effective 1-5-65

1. Indicate Type of Lease
State ☒ Fee ☐

2. State Oil & Gas Lease No.
E906

3. Unit Agreement Name

4. Name of Lessee Name
Ranger

5. Well No.
11

6. Field and Locality of Well
Ranger Lake Penn

7. County
Lea

SUNDRY NOTICES AND REPORTS ON WELLS

THIS FORM IS FOR PROPOSALS TO DRILL OR TO RE-DRILL OR PLUG BACK TO A DIFFERENT RESERVOIR.
IT IS NOT TO BE USED FOR RE-DRILLING OR PLUG BACK TO THE SAME RESERVOIR.

WELL ☐ GAS ☐ OTHER: Injection well (Order R-2754)

1. Name of Lessee
Phillips Petroleum Company

2. Address of Lessee
Room 806, Phillips Building, Odessa, TX 79761

3. Unit Location
UNIT CENTER F 1978 FEET FROM THE north 1978 FEET FROM
west 26 TOWNSHIP 12-S RANGE 34-E NMPM

4. Depth (State whether DF, RT, GR, etc.)
4159' DF

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK ☐ ALTERING CASING ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ CONTINUOUS DRILLING OPERATIONS ☐ PLUG AND ABANDONMENT ☐

PILL OR ALTER CASING ☐ OTHER ☐ CASING TEST AND CEMENT JOBS ☐

OTHER ☐

Describe in detail the operations. Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed operations. (SEE RULE 1103.)

Propose to P&A as follows:

1. MI unit, release tbg f/pkr at 10220', circulate hole w/230 bbls mud laden brine.
2. Spot 50 sx Class C cmt f/10200-9700'. Attempt 25 sx below pkr. Follow down tbg w/37 bbls brine mud, pull tbg to 9600' and reverse clean tbg. Pull tbg to 7500'.
3. Spot 50 sx Class C cmt f/7500'-7000', followed by 24 bbls mud laden brine and pull tbg to above 6900' and reverse clean tbg. Pull tbg to 2875'.
4. Spot 50 sx Class C cmt f/2875-2380' followed down tbg by 8 bbls brine mud. Pull tbg to 2050'.
5. Spot 50 sx Class C cmt f/2050-1560', followed by 5 bbls mud down tbg. Pull tbg to above 1450' and reverse clean; pull tbg to 30'.
6. Spot 10 sx cmt f/30' to surface. Cut off well head, weld on plate and install well marker. Clean location.

Engineering 10/6/76

I, I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *W. J. Mueller* W. J. Mueller TITLE Engineering Advisor DATE 10-6-76

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

OCT 1 1976