

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
SMITH AND MARRS, INC.

3. Address of Operator
1110 N. Big Spring Midland, TX 79701

4. Well Location
Unit Letter I : 1980 Feet From The S Line and 660 Feet From The E Line
Section 13 Township 12S Range 37E NMPM Lea County

10. Elevation (Show whether ~~DF~~, RKB, RF, GR, etc.)
3887'

7. Lease Name or Unit Agreement Name

Shults

8. Well No. 6

9. Pool name or Wildcat
Gladiola

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. WE will notify the OCD before plugging operations begin.

- 1) Rig up pulling unit, tag plug at 11000'
 - 2) Set 100' plug at top of Wolfcamp at 9042.
 - 3) Set 100' plug at top of the Abo at 7725.
 - 4) Run free point on 5 1/2" casing, and cut and pull. Set 100 ' plug at 5 1/2" stub 50' in and 50' out and tag.
 - 5) Set 100' plug at 8 5/8" shoe, 50' in and 50' out, and tag.
 - 6) Set 100' plug at the top of Salt at 2250'.
 - 7) Set 10 sx plug at surface, install dry hole marker, clean location.
- * Hole will be loaded with 10# gel.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Michael L. Pierce TITLE Agent DATE 5-8-91
TYPE OR PRINT NAME Michael L. Pierce TELEPHONE NO. 392-1915

(This space for State Use)

Drig. Sign
Paul Kautz
Geologist

APPROVED BY _____ TITLE _____ DATE MAY 04 1991

CONDITIONS OF APPROVAL, IF ANY: