

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

16. Indicate Type of Lease

State ☐ Fee ☒

5. State Oil & Gas Lease No.

7. Unit Agreement Name

8. Farm or Lease Name

Miller

9. Well No.

1

10. Field and Pool, or Wildcat

Gladiola Rev.

12. County

Lee

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator

Cities Service Oil Company

3. Address of Operator

P. O. Box 69 - Hobbs, New Mexico 88240

4. Location of Well

UNIT LETTER **J**, **1900** FEET FROM THE **South** LINE AND **1900** FEET FROM

THE **East** LINE, SECTION **18** TOWNSHIP **12S** RANGE **30E** NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)

3805 DF

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐

PLUG AND ABANDON ☒

CHANGE PLANS ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

COMMENCE DRILLING OPNS. ☐

CASING TEST AND CEMENT JOB ☐

OTHER ☐

ALTERING CASING ☐

PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the above well as follows:

1. Load hole with mud laden fluid.

2. Set a CI Bridge plug @ 11,900' with a 5 sack cement plug on top.

3. Cut 5 1/2 cgs. @ approx. 9600 and set a 25 sack cement plug, half in and half out of casing stub.

4. Set 25 sack cement plugs @ approx. 7200-7100, 6500-6400, 7000-7700, and 5963-5863.

5. Set 25 sack cement plug @ approx. 4505-4455, half in and half out of 8 5/8" cgs. set @ 4400. Intermediate cement was circulated thru the top of the San Andres @ 4400.

6. Set a 10 sack cement surface plug @ approx. 30-0 with a 4' marker extending 4' above the ground to designate a P & A location.

7. Clear location of all equipment and debris, fill cellar and pits.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. L. Robertson

TITLE **District Clerk**

DATE **11-1-66**

APPROVED BY

SIGNED

ENGINEER

DATE

CONDITIONS OF APPROVAL, IF ANY: