

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION  
 Orig&3cc: OCC, Hobbs  
 cc: Southern Rdgion (West Texas)  
 cc: Partners  
 cc: file

Form C-103  
 Supersedes Old  
 C-102 and C-103  
 Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator SINCLAIR OIL CORPORATION	8. Farm or Lease Name Rosa Shults
3. Address of Operator P. O. Box 1920, Hobbs, New Mexico 88240	9. Well No. 4
4. Location of Well UNIT LETTER L 660 FEET FROM THE West LINE AND 1980 FEET FROM THE South LINE, SECTION 18 TOWNSHIP 12S RANGE 38E NMPM.	10. Field and Pool, or Wildcat Gladiola Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 3875' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.  
 Completed in Devonian perms. 11,932-11,944'. TD 11,945'. PBTD 11,944'.  
 13-3/8"OD casing set @ 316' and cemented w/350 sks. to surface.  
 8-5/8"OD casing set @ 4520' and cemented w/1700 sks. Top of cement behind 8-5/8"OD casing @ 1050' from surface.  
 5-1/2"OD casing set @ 11,945' and cemented w/150 sks. Top of cement behind 5-1/2"OD csg @ 11,040'.  
 PROPOSE TO PLUG AND ABANDON AS FOLLOWS:  
 Fill hole w/heavy mud laden material.  
 Set C.I.B.P. @ approx. 11,200' w/2 sks. cement on top.  
 Cut 5-1/2"OD casing @ approx. 11,000' and pull.  
 Spot 25 sks. cement in top of 5-1/2"OD casing stub.  
 Spot 35 sks. cement plug top of Penn @ 9504'.  
 Spot 35 sks. cement plug top of Wolfcamp @ 9075'.  
 Spot 35 sks. cement plug top of Abo @ 7808'.  
 Spot 35 sks. cement plug top of Glorieta @ 5882'.  
 Spot 25 sks. cement plug in bottom of 8-5/8"OD csg. @ 4520'.  
 Cut 8-5/8"OD casing @ 3420' and pull. Spot 25 sks. cement plug top of 8-5/8"OD csg. stub.  
 Spot 25 sks. cement plug top of Salt @ 2280'. Spot 25 sks. cement plug bottom of 13-3/8" csg. @ 316'. Spot 10 sks. in top of 13-3/8"OD csg. & cellar @ surface. Install regulation dryhole marker, clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Superintendent DATE 3-4-69

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: