

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
30.025. 22746

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
OG-4637

7. Lease Name or Unit Agreement Name

COASTAL STATES

8. Well No. 1

9. Pool name or Wildcat
BAUM UPPER PENN

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
PENROC OIL CORPORATION

3. Address of Operator
P.O. Box 5970, HOBBS, NM 88241

4. Well Location

Unit Letter 0 : 660 Feet From The SOUTH Line and 1980 Feet From The EAST Line

Section 1 Township 14 S Range 32 E NMPM LEA County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:
REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

well data: 13³/₈" @ 371' w/ 350 sxs. 8⁵/₈" @ 4105' w/ 300 sxs.
5¹/₂" @ 10,045' w/ 300 sxs. Perfs: 9839-56'

Plan to plug & abandon as follows: RU workover unit. Swab tbg down to tank battery. TDH w/ tbg. RU wireline & set CIBP @ 9780' w/ 35' cement on top. Determine free point on 5¹/₂" - Cut & pull same. Spot 50 sxs. cement plug 50'-50' @ csg. stub. Spot 50 sxs. plug @ base of 8⁵/₈". Determine Free point on 8⁵/₈". Cut & pull same. Spot 50 sxs plug 50'-50' @ 8⁵/₈" stub. Spot 50 sxs. @ base of 13³/₈". Spot 10 sxs. surface & install dry hole marker. Move PJ, TB etc. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE M. Y. (Merch) Merchant TITLE President DATE 11/21/94
TYPE OR PRINT NAME M. Y. (Merch) Merchant TELEPHONE NO. (505) 397-3596

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: _____

NOTED TO THE BEGINNING OF
THE YEAR FOR THE CLOSING