

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator SUN OIL COMPANY	8. Farm or Lease Name New Mexico U
3. Address of Operator P. O. Box 1861, Midland, Texas	9. Well No. 1
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>N</u> LINE AND <u>660</u> FEET FROM THE <u>W</u> LINE, SECTION <u>34</u> TOWNSHIP <u>14-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat Tres Papalotes (Penn)
15. Elevation (Show whether DF, RT, GR, etc.) 4109 GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Test Wolfcamp & Complete or P&A</u> <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set wireline bridge plug at approximately 10,200' w/3 sx cement on top
2. Perforate 9912-24 (Wolfcamp), treat w/750 gal acid and test.
3. Complete if productive.
4. If non-productive:
 - A. Spot 50 sx plug (450') across perfs.
 - B. POOH. Load hole move out.
 - C. Move in casing pullers. Salvage 5½" casing.
 - D. Spot 75 sx at top of 5½" stub.
 - E. Spot 75 sx at 6100-5785 (Base San Andres) if exposed.
 - F. Spot 75 sx at 4572-4310 (8-5/8" shoe).
 - G. Spot 10 sx plug at surface, cut off casing head and install marker.
 - H. Clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Charles Gray</u>	TITLE <u>Proration Clerk</u>	DATE <u>1-4-72</u>
APPROVED BY <u>John W. Runyan</u>	TITLE <u>Geologist</u>	DATE <u>JAN - 7 1972</u>
CONDITIONS OF APPROVAL, IF ANY:		