

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-23626 ✓
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Carter
8. Well No. 1
9. Pool name or Wildcat Morton Wolfcamp East

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator Samedan Oil Corporation	
3. Address of Operator 10 Desta Drive, Suite 240 East, Midland, Texas 79705	
4. Well Location Unit Letter 0 : 510 Feet From The S Line and 1830 Feet From The E Line Section 33 Township 14-S Range 35-E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4010.2' GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 10,350'. Dump 15' cement.
2. Set CIBP @ 10,200'. Dump 35' cement.
3. Pump 20 sx plug @ 8200-8100'.
4. Cut off, pull and LD 5-1/2" casing.
5. Set cement plug 50' in & 50' out of 5-1/2" casing stub.
6. Set 35 sx plug @ 6174-6074'.
7. Set 35 sx plug @ 4725-4625'.
8. Cut off, pull and LD 8-5/8" casing.
9. Set 45 sx plug 50' in & 50' out of 8-5/8" casing stub.
10. Set 45 sx plug @ 2048-1948'.
11. Set 45 sx plug @ 514-414'.
12. Set 10 sx surface plug.
13. Install plug and abandon marker and restore location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Judy Throneberry TITLE Division Production Clerk DATE 4-27-93  
TYPE OR PRINT NAME Judy Throneberry TELEPHONE NO. 915-684-8491  
ORIGINAL SIGNED BY LEAH SEXTON  
(This space for State Use) DISTRICT I SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

MAY 20 1993