

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-5449

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator The Superior Oil Company 3. Address of Operator P. O. Box 1900, Midland, Texas 79701 4. Location of Well UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>2</u> TOWNSHIP <u>14-S</u> RANGE <u>34-E</u> NMPM.	7. Unit Agreement Name 8. Farm or Lease Name State "H" 9. Well No. 1 10. Field and Pool, or Wildcat Cerca-Upper Penn 15. Elevation (Show whether DF, RT, GR, etc.) KB: 4128' 12. County Lea
---	---

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- (1) Place 50 sack cement plug 10,182' to 9,722' (Perfs 10,173'-10,182').
- (2) Shoot 5-1/2" casing at 8,009'. Pull and recover all 5-1/2" casing above shot point.
- (3) Spot 35 sack cement plug 8,011' to 7,911' at 5-1/2" casing stub.
- (4) Spot 40 sack cement plug 5,528' to 5,428' across Glorietta.
- (5) Spot 50 sack cement plug 4,500' to 4,400' across 8-5/8" casing shoe @ 4,500'.
- (6) Pull as much of 8-5/8" casing as possible (top of cement outside casing at 2050').
- (7) Spot 50 sack cement plug at 8-5/8" casing stub.
- (8) Spot 55 sack cement plug across 11-3/4" casing shoe at 400'.
- (9) Place 10 sack cement plug in top of 11-3/4" casing.
- (10) Install dry hole marker in accordance with OCC rules; level and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. D. Clay T. D. Clay TITLE Petroleum Engineer DATE 11-18-74

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: