

COPIES RECEIVED		
DISTRIBUTION		
DATE		
E		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
NM 212	
7. Unit Agreement Name	
8. Farm or Lease Name	
Viking State	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
North Bagley Penn	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator	
D A & S Oil Well Servicing Incorporated	
3. Address of Operator	
P.O. Box 657 Hobbs New Mexico 88240	
4. Location of Well	
UNIT LETTER A , 660 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 16 TOWNSHIP 12S RANGE 33E NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	
4278 DF	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Run CIBP on W.L. & set @ 8700', cap w/ 5 sx. cmt.

2. Cut 5½" csg. @ 5950'. Circulate 5½" & hole w/ mud laden salt water. Lay down 5½" csg.

3. Spot 40 sx. cmt. plug thru 2 7/8" tbg. from 5950' to 5810'.

4. Spot 40 sx. cmt. plug 50' in & 50' out of bottom of 8 5/8" from 3950' to 3810'.

5. Cut 8 5/8" csg. @ about 1500' and lay down.

6. Spot 75 sx. cmt. plug thru 2 7/8" tbg. from 1500' to 1390'.

7. Spot 75 sx. cmt. plug thru 2 7/8" tbg. in bottom of 13 3/8" csg. from 396' to 306'.

8. Spot 10 sx. cmt plug in top of 13 3/8" csg.

9. Install dry hole marker & clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe D. Ramey TITLE Vice President DATE 5-17-74

APPROVED BY Joe D. Ramey TITLE Director DATE 5-17-74

CONDITIONS OF APPROVAL, IF ANY.

RECEIVED

MAY 17 1974

CH. J. WILSON, COMM.
10300, N. M.