

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-025-27208

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER WORKOVER

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South 4th St., Artesia, NM 88210

7. Lease Name or Unit Agreement Name

San AJK State

8. Well No.

1

9. Pool name or Wildcat

Saunders Permo Upper Penn

4. Well Location

Unit Letter A : 990 Feet From The North Line and 660 Feet From The East Line

Section 32 Township 14S Range 33E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: Propose to add perforations & treat ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

CHANGE WELL NAME FROM SAN STATE #1 - TO: SAN AJK STATE #1

Well formerly operated by MWJ Producing Co., 400 W. Illinois, Suite 1100, Midland, TX 79701

Old perforations: 9496-9977' (Bough); CIBP @ 10055'.

Propose to RUPU. Pick up tubing with bit and/or gauge ring and RIH and tag TD. Perforate 10008, 10010, 10012, 10014, 10016, 10018, 10020 w/2 SPF - total 14 holes, and 10044, 10046, 10048, 10050, 10052 w/1 SPF - total 5 holes. RIH w/tbg and pkr to \pm 10052'. Spot 1 bbl acid, pull pkr to \pm 10030' and set. Acidize w/750 gals 15% NEFE acid. Recover load and swab. POH w/tbg and pkr. RIH w/tbg, pkr and RBP and set RBP @ \pm 10335. Spot 1 bbl 15% acid. Set pkr @ \pm 9990 and acidize w/1250 gals 15% NEFE acid. Swab test.

If production is indicated, put on pump and produce well. If zone is not commercial, will file notice for additional testing.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

Production Supervisor

DATE 7-8-91

TYPE OR PRINT NAME

Juanita Goodlett

TELEPHONE NO. 505/748-1471

(This space for State Use)

ORIGINAL SIGNED BY

DISTRICT I SUPERVISOR

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: