

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 12-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

3a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
McDonald Unit	
8. Farm or Lease Name	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
McDonald Upper Penn	
12. County	
Lea	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

Name of Operator  
Harvey E. Yates Company

Address of Operator  
P.O. Box 1933, Roswell, New Mexico 88201

Location of Well  
UNIT LETTER P 660 FEET FROM THE South LINE AND 990 FEET FROM  
THE East LINE, SECTION 33 TOWNSHIP 13S RANGE 36E NMPM.

11. Elevation (Show whether DF, RT, GR, etc.)  
3951' GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 103.

Casing Size	Wt & GRD	Depth	SXS Cmt	TOC
13 3/8"	48#	367'	400	Surface
8 5/8"	24, 28, & 32#	4611'	2150	Surface
5 1/2"	17, 20#	14,587'	1405	9240' (CBL)

- Recommended Procedure**
- Set CIBP @ 10,000' with 30' cmt on top.  
Pump 100' plug from 9744' to 9644' (top of Wolfcamp)
  - Run free point from 5 1/2" csg.
  - Cut and pull approximately 9000' plus or minus of 5 1/2" csg.
  - Pump plugs as follows:  
100' plug @ 5 1/2" cut off (50' in and out) and tag  
100' plug from 6500' to 6400'  
100' plug from 4611' to 4511' (across 8 5/8" shoe)  
100' plug from 2227' to 2127' (top of Salt)  
50' plug @ surface
  - Install dry hole marker.
- Existing perfs: 10,252-55'

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ray T. Sexton TITLE Production Manager DATE April 02, 1987

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT 1 SUPERVISOR  
APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE APR 7 1987  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED  
FEB 2 1997  
FBI  
COMMUNICATIONS SECTION