

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO.

30-025-28628

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease

LG-3675

7. Lease Name or Unit Agreement Name:

Swan VB State

7. Well No.

#3

8. Pool name or Wildcat

Saunders Permo-Upper Penn

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other ☐

2. Name of Operator

Yates Petroleum Corporation

3. Address of Operator

105 S. 4th Street Artesia, NM 88210

4. Well Location

Unit Letter **L** : **1980** feet from the **South** line and **660** feet from the **West** line

Section **21** Township **14S** Range **33E** NMPM **Lea** County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

4224' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Propose to plug and abandon well as follows:

Pull all equipment out of the hole.

Set a CIBP at 9800' capped with 35' of cement to cover the perfs 9841-10060'.

Pull the 5-1/2" casing from the freepoint to the surface.

Set a 25 sack plug at 7801-7701' to cover the Abo top.

Set a 35 sack plug across the 5-1/2" casing stub expected to be +/- 6950'. Tag plug at least 50' above stub.

Set a 35 sack plug at 5603' across the Glorieta top.

Set a 35 sack plug across the 8-5/8" casing shoe at 4198'. Tag at 4148' or higher.

Set a 35 sack plug across 13-3/8" casing shoe at 445'.

Set a 15 sack plug at the surface.

Remove the wellhead and install a dry hole marker.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Susan Herpin* TITLE Engineering Technician DATE January 11, 2002

Type or print name **Susan Herpin**

Telephone No. **505-748-1471**

(This space for State use)

APPROVED BY _____ TITLE _____ DATE **JAN 18 2002**

Conditions of approval, if any: