

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-77

5a. Indicate Type of Lease	
State ☐	Fee ☒
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. ☐ OIL WELL ☐ GAS WELL ☒ OTHER- <u>Dry</u>		7. Unit Agreement Name
2. Name of Operator <u>AMOCO PRODUCTION COMPANY</u>		8. Farm or Lease Name <u>Peterson "A"</u>
3. Address of Operator <u>P. O. BOX 68 HOBBS, NEW MEXICO 88240</u>		9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>5-S</u> RANGE <u>33-E</u> NMPM.		10. Field and Pool, or Wildcat <u>Peterson Furselman</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>4418' RDB</u>		12. County <u>Roosevelt</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon the subject well as follows:
MISU and POH w/tubing. RIH w/ CIBP and set at 7600'. Cap w/ 35' cement. Pull up and spot 26 BBLs of 10# brine w/ 25# gel/bbl. Spot a 25 SX class H Neat plug across TCMT at 6419 (6500'-6300'). Pull up and spot 46 BBLs brine gel. Perforate 4400'-4401' w/ 4 SSPF. RIH w/ cement retainer and set at 4300'. Pump 40 SX class H Neat and squeeze perfor. Sting out of retainer and dump excess cement. Pull up and spot 20 BBLs brine gel. Perforate 3510-11' w/ 4 SSPF. RIH w/ cement retainer and set at 3200'. Pump 125 SX class H Neat and squeeze perfor. Sting out of retainer and dump excess cement. Pull up and spot 66 BBLs brine gel. Perforate 500-501' w/ 4 SSPF. Established circulation between 5 1/2" - 8 7/8" csg annulus. Pump 250 SX class H Neat cement and circulate cement. Leave full to surface. Cap well erect & marker.

0+5 NMOC-D-H 1-JRB 1-FJN 1-CMH

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Charles D. Serrano</u>	TITLE <u>ADMINISTRATIVE ANALYST (SG)</u>	DATE <u>1/15/86</u>
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT 1 SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE <u>JAN 17 1986</u>
CONDITIONS OF APPROVAL, IF ANY:		