

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Enserch Exploration, Inc.	8. Farm or Lease Name Radcliff
3. Address of Operator P. O. Box 4815, Midland, Texas	9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>32</u> TOWNSHIP <u>45</u> RANGE <u>33E</u> NMPM.	10. Field and Pool, or Wildcat Peterson Mississippi
15. Elevation (Show whether DF, RT, GR, etc.) 4390 G.R.	12. County Roosevelt

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plans are to plug and abandon this well as follows:

A verbal approval was given on 10/9/84 to set CIBP at 7000' and dump 36' cement on plug. Work was performed on 10/10/84.

Proposed

Lay 40 sacks cement plug from 5150'5050.
Cut off 5-1/2" casing at approx. 3000'.
Lay 80 sacks cement plug at 5-1/2" casing cut off 50' in openhole. TIH. Tag plug.
Lay 150 sacks cement plug from 1800-2050'. TIH. Tag plug.
Lay 40 sacks cement plug from 1550-1650'. TIH. Tag plug.
Lay 10 sacks cement plug at surface.

Cut off 9-5/8" casing.
Weld steel plate on 9-5/8" casing.
Install dry hole marker.

Note: Mud-laden fluid between all plug.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED H. F. Burnett TITLE Prod. Superintendent DATE 1/15/85

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT SUPERVISOR

APPROVED BY _____ TITLE _____ DATE JAN 16 1985

CONDITIONS OF APPROVAL, IF ANY: