

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Cities Service Company	8. Farm or Lease Name Griffin A
3. Address of Operator P.O. Box 1919, Midland, Texas 79702	9. Well No. 1 Y
4. Location of Well UNIT LETTER F 1980 FEET FROM THE North LINE AND 2080 FEET FROM THE West LINE, SECTION 26 TOWNSHIP 6S RANGE 33E NMPM.	10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 4381' GR (Est)	12. County Roosevelt

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 8150' Granite. This well was plugged and abandoned in the following manner:

1. RIH w/OE drill pipe and spotted a 50 sack cement plug @ 7723 - 7573' across top of the Penn formation. LDDP to 7271'.
2. Spotted a 50 sack cement plug @ 7271-7121' across the top of the Wolfcamp formation. LDDP to 6605'.
3. Spotted 50 sack cement plug @ 6605 - 6455' across the top of the Abo formation. LDDP to 5869'.
4. Spotted 50 sack cement plug @ 5869-5719' across the top of the Tubb formation. LDDP to 3325'.
5. Spotted 50 sack cement plug @ 3325 - 3175' one-half in and one-half out of 8-5/8" casing shoe @ 3248'. LDDP to 1800'.
6. Spotted 50 sack cement plug @ 1800 - 1606'. LDDP.
7. Spotted a 10 sack cement surface plug @ 30' - 0'.
8. Install a 4" dry hole marker to designate a plugged and abandoned location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Sandy C. Zimmermann TITLE Region Petroleum Engineer DATE 8-27-82

APPROVED BY Ronald M. Carlberry TITLE OIL & GAS INSPECTOR DATE JUN 28 1983

CONDITIONS OF APPROVAL, IF ANY: