

N. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection well</b>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
3. Address of Operator		9. Well No.
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <b>J</b> 1980 FEET FROM THE <b>South</b> LINE AND <b>1080</b> FEET FROM		( <b>Galjamar</b> <b>Grayburg-San Andres</b> )
THE <b>East</b> LINE, SECTION <b>9</b> TOWNSHIP <b>17-S</b> RANGE <b>32-E</b> N.M.P.M.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
<b>CE 4084</b>		<b>Lee</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐

OTHER ☐

PLUG AND ABANDON ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

COMMENCE DRILLING OPNS. ☐

CASING TEST AND CEMENT JOB ☐

OTHER ☐

ALTERING CASING ☐

PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work to commence third quarter 1975. State office will be notified prior to commencing actual plugging operations.

1. Dig pit and cellar.
2. Run in hole with tubing, open ended, to 3700', displace hole with 9.5 ppg mud laden fluid. Spot 25 sxs cement. Pull tubing to 2400' and spot 30 sxs cement. Pull tubing to 1000' and spot 35 sxs cement. Pull out of hole with tubing.
3. Perforate 5 1/2" casing at 363'. Establish circulation, pump sufficient cement to circulate to surface via annulus leaving 5 1/2" casing full.
4. Cut off casing 2-3' below ground level, set 4' marker. Back fill pits and cellar. Clean up location as per federal or state requirements.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. T. Kryszewski TITLE Division Drilling Supt. DATE July 30, 1975

APPROVED BY [Signature] TITLE [Signature] DATE AUG 4 1975

CONDITIONS OF APPROVAL, IF ANY: