

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. <u>30-025-00704</u>
5. Indicate Type of Lease <u>Federal</u> STATE ☐ FEE ☐
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name <u>MCA Unit Bty 4</u>
8. Well No. <u>187</u>
9. Pool name or Wildcat <u>Maljamar B-5A</u>

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL ☐ GAS WELL ☐ OTHER <u>Injection</u>	
2. Name of Operator <u>Conoco Inc.</u>	
3. Address of Operator <u>P.O. Box 460 - Hobbs, New Mexico 88240</u>	
4. Well Location Unit Letter <u>X</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>660</u> Feet From The <u>West</u> Line Section <u>26</u> Township <u>17S</u> Range <u>32E</u> NMPM <u>Lea</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER: ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU. G/H workstring to cement plug at 2054'. If tag on csq collapse at 465', pick up bit & DC & turn thru collapse. If cannot get thru lead csq, procedure will be modified. At 2054' spot 33 bbls mud from 2054'-700'. Displace w/ 2.3 bbls to obtain spot. Pull 1000'. Spot 21 sxs Class "C" w/ 2% CaCl₂ from 1000'-800'. Displace cement w/ 3 bbls. POOH. Establish pump-in rate. Pump 230 sxs class "C" w/ 2% CaCl₂ down csq. Displace cement w/ 4.3 bbls wtr to 175'. Tag 70C at 175'. Shoot squeeze at 150 w/ 4 1/2 spf. Pump 75 sxs class "C" w/ 2% CaCl₂ down csq. Circ to surface. Close csq valve & squeeze remainder of cement away. Leave csq full of cement. Cut off csq and install P&H marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE William W. Baker TITLE Administrative Supervisor DATE May 8, 1989
TYPE OR PRINT NAME William W. Baker TELEPHONE NO. 392-5800

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

nmocd-Hobbs(3)

Approval from BLM should also be obtained

MAY 12 1989