

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-01212 ✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-2118
7. Lease Name or Unit Agreement Name State "G"
8. Well No. 5
9. Pool name or Wildcat Saunders Permian Penn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Charles B. Gillespie, Jr.	3. Address of Operator P.O. Box 8 Midland, TX 79702	4. Well Location Unit Letter H : 2120 Feet From The North Line and 660 Feet From The East Line Section 3 Township 15-S Range 33-E NMPM Lea County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4186' GR, 4199' DF
---	--	--	---	--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Load hole with mud.
2. Cut off and pull 5 1/2" casing from approximately 5000'.
3. Spot 100' cement plug at 5 1/2" casing stub with 50' in and 50' out and tag.
4. Spot 100' cement plug across 8 5/8" shoe at 4235' and tag.
5. Cut off and pull 8 5/8" casing from approximately 900'.
6. Spot 100' cement plug at 8 5/8" casing stub with 50' in and 50' out and tag.
7. Spot 100' cement plug across 13 3/8" shoe at 298'.
8. 15 sx cement plug at surface.
9. Weld 4" marker to surface pipe and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE William R. Crow TITLE Exploration Manager DATE 3/17/93

TYPE OR PRINT NAME William R. Crow

TELEPHONE NO. (915) 683-1765

(This space for State Use) ORIGINAL FILED BY LARRY SEXTON

MAR 18 1993

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: