

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-01215 ✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-2118
7. Lease Name or Unit Agreement Name State "G"
8. Well No. 8
9. Pool name or Wildcat Saunders Permo-Penn

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Charles B. Gillespie, Jr.	
3. Address of Operator P.O. Box 8 Midland, TX 79702	
4. Well Location Unit Letter <u>L</u> : <u>1980</u> Feet From The <u>South</u> Line and <u>660</u> Feet From The <u>West</u> Line Section <u>3</u> Township <u>15-S</u> Range <u>33-E</u> NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4196' GR, 4209' DF	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Load hole with mud. *100' PLUG AT TOP of C casing*
2. Cut off and pull 5 1/2" casing from approximately 4700'.
3. Spot 100' cement plug at 5 1/2" casing stub with 50' in and 50' out and tag.
4. Spot 100' cement plug across 8 5/8" shoe at 4217' and tag.
5. Cut off and pull 8 5/8" casing from approximately 1500'.
6. Spot 100' cement plug at 8 5/8" casing stub with 50' in and 50' out and tag.
7. Spot 100' cement plug across 13 3/8" shoe at 296'.
8. 15 sx cement plug at surface.
9. Weld 4" marker to surface pipe and clean location.

THIS COPY OF THE REPORT OF OPERATIONS IS TO BE FILED IN THE RECORDS OF THE DIVISION OF ENERGY, MINERALS AND NATURAL RESOURCES FOR THE CLOSING OF THE CASE TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

William R. Crow

TITLE

Exploration Manager

DATE 3/19/93

TYPE OR PRINT NAME

William R. Crow

TELEPHONE NO. (915) 683-1765

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

MAR 23 1993