

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-7

5a. Indicate Type of Lease

State ☒

Fee ☐

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Ralph E. Williamson	8. Farm or Lease Name Harrod State
3. Address of Operator PO Box 994, Midland, TX 79702	9. Well No. 1
4. Location of Well UNIT LETTER <u>M U</u> , 660 FEET FROM THE <u>South</u> LINE AND 660 FEET FROM THE <u>West</u> LINE, SECTION <u>4</u> TOWNSHIP <u>16S</u> RANGE <u>20E 35</u> N.M.P.M.	10. Field and Pool, or WHdcat Townsend Strawn
15. Elevation (Show whether DF, RT, CR, etc.) 4043 DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- (1) Set CIBP @ 11280, 50' above perforated Strawn interval from 11330-11390', put 35' of cement on plug.
- (2) Load hole w/ 10# brine w/25#/bbl gel to point where 4 1/2" casing is to severed.
- (3) Cut 4 1/2" @ 9400'± lay down pipes and set cement plug from 9580' (@ Top of Wolfcamp) to 50' above stubb of 4 1/2 (to 9350'±), tag plug.
- (4) Set 100' or 25 sx plug, which ever is greater @ 7570-7470', do not tag.
- (5) Set 100' or 25 sx plug, whichever is greater @ 6160-6060', do not tag.
- (6) Set 100' plug across stuffed 9 5/8" casing from 4590-4490'. End of 9 5/8" @ 4540' tag this plug.
- (7) Set 100' plug @ 1790' @ top of salt, do not tag.
- (8) Set 100' plug from 407-307', end of 13 3/8" @ 357', tag plug.
- (9) set 10' plug in surface, and erect dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mary Anderson TITLE Production DATE 1-6-88  
Orig. Signed by Paul Kautz  
APPROVED BY Geologist TITLE  DATE JAN 11 1988  
CONDITIONS OF APPROVAL, IF ANY: