

FORMATIONS (Continued)

<u>FROM:</u>	<u>TO:</u>	<u>FEET:</u>	<u>FORMATION</u>
10807	10831	24	Lime & shale
10831	10837	6	Lime
10837	10863	26	Shale
10863	10905	42	Shale & lime
10905	10934	29	Lime
10934	10968	34	Lime & shale
10968	10983	15	Lime
10983	11006	23	Lime & shale
11006	11138	132	Lime
11138	11166	28	Lime & shale
11166	11190	24	Lime
11190	11197	7	Lime & shale
11197	11308	111	Lime
11308	11322	14	Lime & shale
11322	11350	28	Shale
11350	11357	7	Lime
11357	11383	26	Shale & lime
11383	11399	16	Shale
11399	11439	40	Lime
11439	11455	16	Shale
11455	11480	25	Lime & shale
11480	11577	97	Shale
11577	11599	22	Lime
	11599		Total Depth
11599	10587	1012	P.B.T.D. as follows: 75 sacks cement in open hole 11599' to 11355' with heavy mud laden fluid in hole. Set 5-1/2" OD casing at 10,630'. After casing cemented, drilled cement plug inside 5-1/2" OD casing to 10,587', leaving 43' cement inside of casing from 10,587' to 10,630'.