

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Sinclair Oil & Gas Company	8. Farm or Lease Name Eidson "C" WN
3. Address of Operator P.O. Box 1920, Hobbs, New Mexico	9. Well No. 1
4. Location of Well UNIT LETTER G 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 35 TOWNSHIP 16S RANGE 35E NMPM.	10. Field and Pool, or Wildcat Shoe Bar Devonian
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103.

12,678TD 13-3/8csg set @ 349 & circulated to surface.
9-5/8csg set @ 4885 & circulated to surface.
5-1/2csg set @ 12582 & cemented back to 10410' fr surface.

PROPOSE TO PLUG AND ABANDON WELL AS FOLLOWS: (With heavy mud between cement plugs)

Set 25 sk cement plug at bottom of 5-1/2" csg.
Cut & pull 5-1/2" csg fr appr 10400'.
Set 25 sk cement plug in top of 5-1/2" csg stub.
Set 25 sk cement plug across top of Penn. Zone. (Top of Penn: 10320')
Set 25 sk cement plug across top of Wolfcamp Zone (top of Wolfcamp: 9440)
Set 25 sk cement plug across top of Abo Zone (top of Abo: 8246)
Set 25 sk cement plug across top of Glorieta Zone (top of Glorieta: 6227)
Set 25 sk cement plug across bottom of 9-5/8 csg.
Set 10 sk cement at surface w/regulation marker.
Clean & level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Supt. DATE 3-30-67

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: 35 sk cement plug at 10410' fr surface