

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-10640	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input checked="" type="checkbox"/> Plug & Abandon		7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company		8. Farm or Lease Name Ramco <del>State</del> WN
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240		9. Well No. 1
4. Location of Well UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>36</u> TOWNSHIP <u>16S</u> RANGE <u>35E</u> NMPM.		10. Field and Pool, or Wildcat Undesignated
15. Elevation (Show whether DF, RT, GR, etc.) Unknown		12. County Lea

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 5303'.  
13-3/8" OD 32.40# csg set @ 317' & cmtd w/250 sx.  
8-5/8" OD 32# csg set @ 3321' & cmtd w/350 sx.  
Open hole 3321'-5303'. This well was drilled in 1945 to test the San Andres and was unproductive. A cmt plug was set from 5000' to TD of 5303' and in 8-5/8" csg from 3270' to base of 8-5/8" csg @ 3321'. The hole was filled w/heavy acquagel mud above & below plugs. Proposed to plug and abandon in the following manner: Install BOP. Cut off 8-5/8" OD csg from free point. Spot 50 sx cmt plug in & out of 8-5/8" csg stub. Spot 50 sx cmt plug across 13-3/8" OD csg shoe @ 317'. Spot 10 sk cmt plug @ surface. Erect regulation dry hole marker. Clean & level location.

*100' plug @ top 50 ft*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED H. J. Bernard TITLE Dist. Drlg. Supv. DATE 12/30/74

APPROVED BY Orin Stedley TITLE Asst. Dir. DATE 1/1/75

CONDITIONS OF APPROVAL, IF ANY: