

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
E-1075

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> T.A. GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name Lea 396 State
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 4
4. Location of Well UNIT LETTER <u>B</u> <u>660</u> FEET FROM THE <u>North</u> <u>1980</u> FEET FROM THE <u>East</u> <u>35</u> LINE, SECTION <u>15-S</u> TOWNSHIP <u>36-E</u> RANGE <u>36-E</u> NMPM.	10. Field and Pool, or Wildcat Dean/Permo-Penn
15. Elevation (Show whether DF, RT, GR, etc.) 3859' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLUG <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. SEE RULE 1103.

This well has been depleted and shut-in since 1961. No remedial or secondary possibilities exist. We propose to P & A as follows:

- Set CIBP @ about 11,440' and cap w/2 sx cement.
- Cut off and recover 5½" casing from freepoint (T/C @ 9400').
- Use 9#/gal gel mud and spot these cement plugs:
30 sx in & out of 5½" stub
30 sx across top of Ahn at 8373' if 5½" stub below this depth
30 sx across top of Glorieta at 6487' if 5½" stub below this depth
30 sx in & out of 9-5/8" shoe @ 4922'
10 sx in top of well
- 13-3/8" & 9-5/8" casing strings will remain intact. Dry hole marker will be erected and location cleared & levelled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED AD Bratches TITLE Dist. Drlg. Supervisor DATE 5/3/71
APPROVED BY John J. McNeely TITLE SUPERVISOR DISTRICT 1 DATE MAY 5 1971
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

MAY 4 1971

**OIL CONSERVATION COMM.
HOBBS, N. M.**