

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

JAN 27 10 21 AM '66

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Sinclair Oil & Gas Company	8. Farm or Lease Name T.D. Pope
3. Address of Operator P.O. Box 1920, Hobbs, N.M.	9. Well No. 12
4. Location of Well UNIT LETTER K, 510 2/30, FEET FROM THE South North LINE AND 330 1650 FEET FROM THE West LINE, SECTION 36 TOWNSHIP 14S RANGE 37E NMPM.	10. Field and Pool, or Wildcat Denton Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3801GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Present Depth: 9467' PB 13-3/8" csg set @ 314' & cement circulated  
9-5/8" csg set @ 4768' & cemented back to 1890'  
7" csg set at 9467' & cemented back to 7510'.  
7" csg perforated 9232-9449

PROPOSE TO PLUG AND ABANDON WELL AS FOLLOWS:

Set cement retainer at 5000' & set cement plug from 5000' to 9467'.  
Cut & pull 7" csg & place 25 sack cement plug in top of 7" csg stub.  
Cut & pull 9-5/8" csg & place 25 sack cement plug in bottom of 9-5/8" csg.  
(note: in event 7" csg is cut & pulled in vicinity of bottom of 9-5/8" csg at 4768', one plug will be set covering top of 7" stub & bottom of 9-5/8" csg.)  
Place 25 sack cement plug in top of 9-5/8" csg stub.  
Place 25 sack cement plug in bottom of 13-3/8" csg.  
Place 10 sack cement plug in top of 13-3/8" csg, set regulation dry hole marker, clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Supt. DATE 1-26-66

APPROVED BY [Signature] TITLE  DATE

CONDITIONS OF APPROVAL, IF ANY: