

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-8944	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Skelly Oil Company		8. Farm or Lease Name Mexico "F"
3. Address of Operator P. O. Box 1351, Midland, Texas 79701		9. Well No. 8
4. Location of Well UNIT LETTER D, 967 FEET FROM THE North LINE AND 990 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 15S RANGE 37E NMPM.		10. Field and Pool, or Wildcat Denton Wolfcamp
15. Elevation (Show whether DF, RT, GR, etc.) 3816' DF		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has been temporarily abandoned since October 1, 1971. We propose to plug and abandon this well as follows:

- Move in casing pulling unit.
- Set cast iron bridge plug above uppermost perforations at 9160' and cap with cement to approximately 9125'.
- Locate free point, cut off and salvage approximately 5500' of 5-1/2" OD casing.
- Spot 50 sack cement plug across top of 5-1/2" OD casing stub.
- Spot 50 sack cement plug across bottom of 9-5/8" OD casing at 4782'.
- Spot 50 sack cement plug across top of salt section at 2079'.
- Spot 10 sack cement plug from surface to approximately 28'.
- Set dry hole marker.

All intervals not cemented will be filled with 10# mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

J. R. Avent

District Admin. Coordinator

December 28, 1973

SI D TITLE DATE

APPROVED BY TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: